

ProTeam Vac Station

ProTeam's newly enhanced Vac Station is an essential tool for maintaining a more efficient, safe, and organized cleaning environment. The Vac Station has two options: a single-shelf version designed for our corded products and an option with two shelves that can house a cordless unit and a ProTeam charger and battery. Both Vac Station options feature accessory hooks ideal for storing a wand and a power cord. Mounted on a robust adjustable steel wall bracket, the shelves can easily be moved up and down, ensuring operators of all heights can access their stored equipment ergonomically.



Optimize your space.

Mounting the Vac Station frees up floor space, improves organization, while helping to reduce damage to equipment.



Reduce tripping hazards.

The Vac Station helps maintain a safe environment by reducing the amount of clutter on the floor.



Easily put on your vac.

Back up to the Vac Station and then loop your arms through the shoulder straps to begin cleaning.



Join The Movement

Perfect storage and organization for:

GoFit® Corded Series
GoFit Cordless Series
GoFree® Flex Pro II
ProVac® FS 6
Super Coach Pro®
Legacy backpack models



The ProTeam Vac Station measures 12.5" deep, 4.5" high and 15" wide. The sturdy steel wall bracket is mounted to the wall with three screws and allows for customizable height. Crevice tools and floor tools slide into the holes behind the vacuum on the base for storage. An extension cord can hang from one side while wands are held upright on the other, using the attachable accessories.



107793

Vac Station Complete
w/ Mounting Hardware



107794

Vac Station, 2-Shelves,
w/ Mounting Hardware

Installing your ProTeam Vac Station

Use the instructions below to quickly and easily install your Vac Station.

- 1** Use a stud finder in the area you want to install the Vac Station and mark its location.
- 2** Using a measuring tape, mark 36" from the floor. This will be the location of the middle mounting hole.
- 3** Using a 1/8" drill bit, create a hole 2" deep on the middle mounting hole location. Then, line the bracket to the middle mounting hole and insert a wall bracket screw.
- 4** Next, align the bracket vertically and mark the location of the other screw points at both ends of the bracket.
- 5** Rotate the bracket to the side as you use the 1/8" drill bit to make two more holes at either end.
- 6** Rotate the bracket back to its vertical position then place the two screws into the holes and tighten.
- 7** Line up the standard guide and mounting bracket on the Vac Station. Mount the station at the proper height.
- 8** The proper height of the Vac Station is determined by the user. The individual should be able to back into the station without bending or raising themselves.
- 9** Task completed! Now add the vacuum and tools and accessories for efficient storage.

 ProTeam

proteam.emerson.com

866.888.2168

customerservice.proteam@emerson.com



The American Lung Association does not endorse product, device or service.



EMERSON

500124 8/24